



Nakato
— PORCELAIN —

CONTENT

PAGE 8-33



PEARL EDITION

COLOURS

PAGE 10-13 PAGE 14-17 PAGE 18-21 PAGE 22-25 PAGE 26-29 PAGE 30-33



PAGE 34-63




DESERT EDITION

PAGE 36-39 PAGE 40-43 PAGE 44-47 PAGE 48-51 PAGE 52-55 PAGE 56-59 PAGE 60-63



PAGE 64-77



GLASSY EDITION

PAGE 66-69 PAGE 70-73 PAGE 74-77




PAGE 78-85



FINE ART

PAGE 78-85



Nankato

PORCELAIN





PEARL



DESERT



GLASSY



FINE ART

PRODUCT GUIDANCE



Quality

Our Premium Fine Porcelain has the composition of Kaolin, Ball Clay, Feldspar and Silica, we have created our own glaze formula and use pure raw materials with the finest quality. Being fired at 1,250°C, this temperature range makes the products durable for serving all functional usage with 0% water absorption. Besides, our products are specially designed to maximize strength, reduce cracking and chipping.




Design & Function

Our products are designed with multi-functional concept aiming to be a smart solution for all different purposes. For example, various creative stackable items suit the idea of storage and facilitates space saving.




Dishwasher & Microwave Safe

The products are safe to use with industrial dishwashing machine. The glaze and decoration do not stain or lose their brilliance or color. With dishwashing machine, it can be in excess of 1,000 cycles. Our products are also guaranteed to be completely microwave safe.



Thermal Shock & Craze Resistance

Our products are tested at the extreme temperature condition. The products can resist the sudden change from freezer to microwave.



Lead & Cadmium Free

Our Products are tested and passed the lead & cadmium free under standard test FDA, California Proposition 65 and EU Directive 84/500 EEC. Our product is safe and hygienic to be used as food container.



Cut & Scratch Resistance

The hardness of our glaze prevents any cut & scratch remaining on the surface. We pay special attention to polish and form the foot of our tableware in order to guarantee a smooth foot to reduce the risk of abrasion and scratching during stacking.

GEM SERIES

Color glaze and Matt Glaze finishes on product will tend to show wear and tear to a greater degree. Please use the product with special care to extend its life cycle and to preserve its appearance.

SATIN SERIES

Color glaze and Matt Glaze finishes on product will tend to show wear and tear to a greater degree. Please use the product with special care to extend its life cycle and to preserve its appearance.







SAND SERIES

Color glaze and Matt Glaze finishes on product will tend to show wear and tear to a greater degree. Please use the product with special care to extend its life cycle and to preserve its appearance.

PEARL EDITION

PEARL EDITION shine every second the memorable moment. This special luster styling will delight your dining experience.



-  LIGHT GREY
-  BEIGE
-  BROWN
-  GREY
-  MINT
-  NAVY BLUE

Light Grey



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75605A
CUP B
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75615A
CUP B
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75620A
CUP B
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")



75643A
CUP B
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75625A
MUG B
250 cc. (8.45 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



75634A
MUG B
350 cc. (11.8 Oz.)

Light Grey



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Beige



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75605A
CUP B
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75615A
CUP B
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75620A
CUP B
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")



75643A
CUP B
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75625A
MUG B
250 cc. (8.45 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



75634A
MUG B
350 cc. (11.8 Oz.)

Beige

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")




75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Brown



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")

75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")

75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")

75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")

75002A
COUPE PLATE
16 cm. (6.3")

75022A
COUPE PLATE
21 cm. (8.27")

75052A
COUPE PLATE
26 cm. (10.24")

75072A
COUPE PLATE
30 cm. (11.8")

75034A
DEEP COUPE PLATE
21.5 cm. (8.46")

75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")

75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")

75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")

75511A
BOWL
12 cm. (4.72")

75521A
BOWL
15 cm. (5.9")

75524A
BOWL
18 cm. (7")

75517A
BOWL
13 cm. (5.12")

75531A
LOW BOWL
17 cm. (6.7")

75532A
LOW BOWL
19 cm. (7.48")

75533A
LOW BOWL
21 cm. (8.27")

75529A
BOWL
16 cm. (6.3")

75600A
CUP
100 cc. (3.38 Oz.)

75301A
SAUCER
12.5 cm. (4.92")

75611A
CUP
200 cc. (6.76 Oz.)

75302A
SAUCER
15 cm. (5.9")

75616A
CUP
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")

75601A
CUP A
100 cc. (3.38 Oz.)

75307A
SAUCER
12.5 cm. (4.92")

75612A
CUP A
200 cc. (6.76 Oz.)

75308A
SAUCER
15 cm. (5.9")

75617A
CUP A
250 cc. (8.45 Oz.)

75308A
SAUCER
15 cm. (5.9")

75605A
CUP B
100 cc. (3.38 Oz.)

75301A
SAUCER
12.5 cm. (4.92")

75615A
CUP B
200 cc. (6.76 Oz.)

75302A
SAUCER
15 cm. (5.9")

75620A
CUP B
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")

75641A
CUP
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")

75642A
CUP A
350 cc. (11.8 Oz.)

75310A
SAUCER
16 cm. (6.3")

75643A
CUP B
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")

75621A
MUG
250 cc. (8.45 Oz.)

75626A
MUG
300 cc. (10.15 Oz.)

75631A
MUG
350 cc. (11.8 Oz.)

75625A
MUG B
250 cc. (8.45 Oz.)

75622A
MUG A
250 cc. (8.45 Oz.)

75627A
MUG A
300 cc. (10.15 Oz.)

75633A
MUG A
350 cc. (11.8 Oz.)

75634A
MUG B
350 cc. (11.8 Oz.)

Brown



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")




75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Grey



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")

75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")

75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")

75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")

75002A
COUPE PLATE
16 cm. (6.3")

75022A
COUPE PLATE
21 cm. (8.27")

75052A
COUPE PLATE
26 cm. (10.24")

75072A
COUPE PLATE
30 cm. (11.8")

75034A
DEEP COUPE PLATE
21.5 cm. (8.46")

75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")

75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")

75057A
DEEP COUPE PLATE
25.5 cm. (10")

75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")

75511A
BOWL
12 cm. (4.72")

75521A
BOWL
15 cm. (5.9")

75524A
BOWL
18 cm. (7")

75517A
BOWL
13 cm. (5.12")

75531A
LOW BOWL
17 cm. (6.7")

75532A
LOW BOWL
19 cm. (7.48")

75533A
LOW BOWL
21 cm. (8.27")

75529A
BOWL
16 cm. (6.3")

75600A
CUP
100 cc. (3.38 Oz.)

75301A
SAUCER
12.5 cm. (4.92")

75611A
CUP
200 cc. (6.76 Oz.)

75302A
SAUCER
15 cm. (5.9")

75616A
CUP
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")

75601A
CUP A
100 cc. (3.38 Oz.)

75307A
SAUCER
12.5 cm. (4.92")

75612A
CUP A
200 cc. (6.76 Oz.)

75308A
SAUCER
15 cm. (5.9")

75617A
CUP A
250 cc. (8.45 Oz.)

75308A
SAUCER
15 cm. (5.9")

75605A
CUP B
100 cc. (3.38 Oz.)

75301A
SAUCER
12.5 cm. (4.92")

75615A
CUP B
200 cc. (6.76 Oz.)

75302A
SAUCER
15 cm. (5.9")

75620A
CUP B
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")

75641A
CUP
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")

75642A
CUP A
350 cc. (11.8 Oz.)

75310A
SAUCER
16 cm. (6.3")

75643A
CUP B
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")

75621A
MUG
250 cc. (8.45 Oz.)

75626A
MUG
300 cc. (10.15 Oz.)

75631A
MUG
350 cc. (11.8 Oz.)

75625A
MUG B
250 cc. (8.45 Oz.)

75622A
MUG A
250 cc. (8.45 Oz.)

75627A
MUG A
300 cc. (10.15 Oz.)

75633A
MUG A
350 cc. (11.8 Oz.)

75634A
MUG B
350 cc. (11.8 Oz.)

Grey



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Mint



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75511A
BOWL
12 cm. (4.72")




75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75616A
CUP
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75612A
CUP A
200 cc. (6.76 Oz.)



75617A
CUP A
250 cc. (8.45 Oz.)

75308A
SAUCER
15 cm. (5.9")



75605A
CUP B
100 cc. (3.38 Oz.)



75615A
CUP B
200 cc. (6.76 Oz.)



75620A
CUP B
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75642A
CUP A
350 cc. (11.8 Oz.)



75643A
CUP B
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75625A
MUG B
250 cc. (8.45 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



75634A
MUG B
350 cc. (11.8 Oz.)

Mint



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75517A
BOWL
13 cm. (5.12")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75529A
BOWL
16 cm. (6.3")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75605A
CUP B
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75615A
CUP B
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75620A
CUP B
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")



75643A
CUP B
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75625A
MUG B
250 cc. (8.45 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



75634A
MUG B
350 cc. (11.8 Oz.)




SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.




75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

DESERT EDITION

DESERT EDITION were blended the unique texture details together to create the story of timeless touch and reveal the joy of natural phenomena, satisfying all pleasure demands.



- BLACK
- BEIGE
- BLUE
- GREY
- LIGHT BLUE
- LIGHT GRAY
- RED



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
 FLAT PLATE / WIDE RIM
 25 cm. (9.84")
 RIM 7 cm. (2.76")



75045A
 FLAT PLATE / WIDE RIM
 30 cm. (11.8")
 RIM 7.5 cm. (3")



75205A
 DEEP PLATE / WIDE RIM B
 27 cm. (10.63")
 WELL 17 cm. (6.69")



75202A
 DEEP PLATE / WIDE RIM B
 31 cm. (12")
 WELL 18.1 cm. (7.13")



75527A
 BOWL / WIDE RIM
 21 cm. (8.27")
 WELL 11 cm. (4.33")



75556A
 BOWL / WIDE RIM
 24 cm. (9.45")
 WELL 12 cm. (4.72")

Beige



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



95201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



95524A
BOWL
18 cm. (7")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)

Beige



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)




75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)

SCAPE


SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.




75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")




75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75616A
CUP
250 cc. (8.45 Oz.)



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75617A
CUP A
250 cc. (8.45 Oz.)



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")

75642A
CUP A
350 cc. (11.8 Oz.)



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
 FLAT PLATE / WIDE RIM
 25 cm. (9.84")
 RIM 7 cm. (2.76")



75045A
 FLAT PLATE / WIDE RIM
 30 cm. (11.8")
 RIM 7.5 cm. (3")



75205A
 DEEP PLATE / WIDE RIM B
 27 cm. (10.63")
 WELL 17 cm. (6.69")



75202A
 DEEP PLATE / WIDE RIM B
 31 cm. (12")
 WELL 18.1 cm. (7.13")



75527A
 BOWL / WIDE RIM
 21 cm. (8.27")
 WELL 11 cm. (4.33")



75556A
 BOWL / WIDE RIM
 24 cm. (9.45")
 WELL 12 cm. (4.72")

Light Blue



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)

Light Blue



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

Light Grey



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)

75302A
SAUCER
15 cm. (5.9")

75616A
CUP
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)

75308A
SAUCER
15 cm. (5.9")

75617A
CUP A
250 cc. (8.45 Oz.)

75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")

75642A
CUP A
350 cc. (11.8 Oz.)

75310A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)

Light Grey



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75611A
CUP
200 cc. (6.76 Oz.)



75616A
CUP
250 cc. (8.45 Oz.)



75601A
CUP A
100 cc. (3.38 Oz.)



75612A
CUP A
200 cc. (6.76 Oz.)



75617A
CUP A
250 cc. (8.45 Oz.)



75641A
CUP
350 cc. (11.8 Oz.)



75642A
CUP A
350 cc. (11.8 Oz.)



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)

SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")

GLASSY EDITION

GLASSY EDITION were originated from irresistible desire to create distinguished style. It surely provides an inspiration to all types of cuisine.

- BLACK
- GREEN
- TAUPE





95001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



95021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



95051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



95071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



95002A
COUPE PLATE
16 cm. (6.3")



95022A
COUPE PLATE
21 cm. (8.27")



95052A
COUPE PLATE
26 cm. (10.24")



95072A
COUPE PLATE
30 cm. (11.8")



95034A
DEEP COUPE PLATE
21.5 cm. (8.46")



95171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



95191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



95201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



95057A
DEEP COUPE PLATE
25.5 cm. (10")



95511A
BOWL
12 cm. (4.72")



95521A
BOWL
15 cm. (5.9")



95524A
BOWL
18 cm. (7")



95531A
LOW BOWL
17 cm. (6.7")



95532A
LOW BOWL
19 cm. (7.48")



95533A
LOW BOWL
21 cm. (8.27")



95600A
CUP
100 cc. (3.38 Oz.)



95301A
SAUCER
12.5 cm. (4.92")



95611A
CUP
200 cc. (6.76 Oz.)



95302A
SAUCER
15 cm. (5.9")



95616A
CUP
250 cc. (8.45 Oz.)



95302A
SAUCER
15 cm. (5.9")



95601A
CUP A
100 cc. (3.38 Oz.)



95307A
SAUCER
12.5 cm. (4.92")



95612A
CUP A
200 cc. (6.76 Oz.)



95308A
SAUCER
15 cm. (5.9")



95617A
CUP A
250 cc. (8.45 Oz.)



95308A
SAUCER
15 cm. (5.9")



95641A
CUP
350 cc. (11.8 Oz.)



95309A
SAUCER
16 cm. (6.3")



95642A
CUP A
350 cc. (11.8 Oz.)



95310A
SAUCER
16 cm. (6.3")



95621A
MUG
250 cc. (8.45 Oz.)



95626A
MUG
300 cc. (10.15 Oz.)



95631A
MUG
350 cc. (11.8 Oz.)



95622A
MUG A
250 cc. (8.45 Oz.)



95627A
MUG A
300 cc. (10.15 Oz.)



95633A
MUG A
350 cc. (11.8 Oz.)



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



95044A
 FLAT PLATE / WIDE RIM
 25 cm. (9.84")
 RIM 7 cm. (2.76")



95045A
 FLAT PLATE / WIDE RIM
 30 cm. (11.8")
 RIM 7.5 cm. (3")



95205A
 DEEP PLATE / WIDE RIM B
 27 cm. (10.63")
 WELL 17 cm. (6.69")



95202A
 DEEP PLATE / WIDE RIM B
 31 cm. (12")
 WELL 18.1 cm. (7.13")



95527A
 BOWL / WIDE RIM
 21 cm. (8.27")
 WELL 11 cm. (4.33")



95556A
 BOWL / WIDE RIM
 24 cm. (9.45")
 WELL 12 cm. (4.72")

Green



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



95072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)

75302A
SAUCER
15 cm. (5.9")

75616A
CUP
250 cc. (8.45 Oz.)

75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)

75308A
SAUCER
15 cm. (5.9")

75617A
CUP A
250 cc. (8.45 Oz.)

75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)

75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)

75310A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")



75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75034A
DEEP COUPE PLATE
23 cm. (8.46")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



95511A
BOWL
12 cm. (4.72")



95521A
BOWL
15 cm. (5.9")



95524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")




75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")




75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
 FLAT PLATE / WIDE RIM
 25 cm. (9.84")
 RIM 7 cm. (2.76")



75045A
 FLAT PLATE / WIDE RIM
 30 cm. (11.8")
 RIM 7.5 cm. (3")



75205A
 DEEP PLATE / WIDE RIM B
 27 cm. (10.63")
 WELL 17 cm. (6.69")



75202A
 DEEP PLATE / WIDE RIM B
 31 cm. (12")
 WELL 18.1 cm. (7.13")



75527A
 BOWL / WIDE RIM
 21 cm. (8.27")
 WELL 11 cm. (4.33")



75556A
 BOWL / WIDE RIM
 24 cm. (9.45")
 WELL 12 cm. (4.72")

FINE ART

FINE ART is the real player on tabletop stage. Each motivation item performs its part supremely that magor magnificence atmosphere conveys. capturing the hearts of all audiences.





75001A
FLAT PLATE
16 cm. (6.3")
RIM 2.4 cm. (0.94")



75021A
FLAT PLATE
21 cm. (8.27")
RIM 3.4 cm. (1.34")



75051A
FLAT PLATE
27 cm. (10.63")
RIM 4.2 cm. (1.65")



75071A
FLAT PLATE
31 cm. (12")
RIM 4.8 cm. (1.89")



75002A
COUPE PLATE
16 cm. (6.3")



75022A
COUPE PLATE
21 cm. (8.27")



75052A
COUPE PLATE
26 cm. (10.24")



75072A
COUPE PLATE
30 cm. (11.8")



75171A
DEEP PLATE
23 cm. (9")
WELL 14.6 cm. (5.75")



75191A
DEEP PLATE
27 cm. (10.63")
WELL 16.3 cm. (6.42")



75201A
DEEP PLATE
31 cm. (12")
WELL 19 cm. (7.5")



75231A
OVAL PLATE
24 cm. (9.45")



75251A
OVAL PLATE
30 cm. (11.8")



75261A
OVAL PLATE
36 cm. (14")



75034A
DEEP COUPE PLATE
21.5 cm. (8.46")



75057A
DEEP COUPE PLATE
25.5 cm. (10")



75511A
BOWL
12 cm. (4.72")



75521A
BOWL
15 cm. (5.9")



75524A
BOWL
18 cm. (7")



75531A
LOW BOWL
17 cm. (6.7")



75532A
LOW BOWL
19 cm. (7.48")



75533A
LOW BOWL
21 cm. (8.27")



75517A
BOWL
13 cm. (5.12")



75529A
BOWL
16 cm. (6.3")



75600A
CUP
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75611A
CUP
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75616A
CUP
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75641A
CUP
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75601A
CUP A
100 cc. (3.38 Oz.)



75307A
SAUCER
12.5 cm. (4.92")



75612A
CUP A
200 cc. (6.76 Oz.)



75308A
SAUCER
15 cm. (5.9")



75617A
CUP A
250 cc. (8.45 Oz.)



75308A
SAUCER
15 cm. (5.9")



75642A
CUP A
350 cc. (11.8 Oz.)



75310A
SAUCER
16 cm. (6.3")




75605A
CUP B
100 cc. (3.38 Oz.)



75301A
SAUCER
12.5 cm. (4.92")



75615A
CUP B
200 cc. (6.76 Oz.)



75302A
SAUCER
15 cm. (5.9")



75620A
CUP B
250 cc. (8.45 Oz.)



75302A
SAUCER
15 cm. (5.9")



75643A
CUP B
350 cc. (11.8 Oz.)



75309A
SAUCER
16 cm. (6.3")



75621A
MUG
250 cc. (8.45 Oz.)



75626A
MUG
300 cc. (10.15 Oz.)



75631A
MUG
350 cc. (11.8 Oz.)



75622A
MUG A
250 cc. (8.45 Oz.)



75627A
MUG A
300 cc. (10.15 Oz.)



75633A
MUG A
350 cc. (11.8 Oz.)



75806A
TEA POT WITH LID
500 cc. (17 Oz.)



75810A
TEA POT WITH LID
1,000 cc. (33.82 Oz.)



75811A
SUGAR BOWL
250 cc. (8.45 Oz.)



75817A
CREAMER
200 cc. (6.76 Oz.)



75625A
MUG B
250 cc. (8.45 Oz.)



75634A
MUG B
350 cc. (11.8 Oz.)



75807A
TEA POT A WITH LID
500 cc. (17 Oz.)



75809A
TEA POT A WITH LID
1,000 cc. (33.82 Oz.)



75812A
SUGAR BOWL A
200 cc. (6.76 Oz.)



75820A
CREAMER A
200 cc. (6.76 Oz.)



75903A
SHAKER 3 HOLES



75904A
SHAKER 1 HOLE



SCAPE

SCAPE the perfect pride, astonish everyone at all time. Each masterpiece creates user the touchable history of impression.



75044A
FLAT PLATE / WIDE RIM
25 cm. (9.84")
RIM 7 cm. (2.76")



75045A
FLAT PLATE / WIDE RIM
30 cm. (11.8")
RIM 7.5 cm. (3")



75075A
FLAT PLATE / WIDE RIM A
30 cm. (11.8")
RIM 6.8 cm. (2.68")



75076A
FLAT PLATE / WIDE RIM A
30 cm. (11.8")
RIM 9 cm. (3.54")



75181A
DEEP PLATE / WIDE RIM
25 cm. (9.8")
WELL 12.2 cm. (4.8")



75203A
DEEP PLATE / WIDE RIM A
31 cm. (12")
WELL 15 cm. (5.9")



75204A
SQUARE GOURMET PLATE
30 cm. (11.8")
WELL 16.2 cm. (6.38")



75915A
COVER
15.5 cm. (6.1")
(Fits 95045A, 95203A)



75914A
COVER
19 cm. (7.48")
(Fits 95202A)



75205A
DEEP PLATE / WIDE RIM B
27 cm. (10.63")
WELL 17 cm. (6.69")



75202A
DEEP PLATE / WIDE RIM B
31 cm. (12")
WELL 18.1 cm. (7.13")



75527A
BOWL / WIDE RIM
21 cm. (8.27")
WELL 11 cm. (4.33")



75556A
BOWL / WIDE RIM
24 cm. (9.45")
WELL 12 cm. (4.72")



EMMERICH IMPEX PVT LTD

64/928, Krishnaswamy Road, Pullepady, Kochi-682 035. Tel: 0484-4067764, info@emmerichimpex.com

www.nakato.in